



Pošto se telefon sklopi i uključi u mrežu proverava se koju je IP adresu dobio.

- ❖ Pritisne se taster Setup (taster na kojem je nacrtano pismo)
- ❖ Potom se spuštamo strelicom na dole do opcije Network ili tasterom 9 pređemo direktno na nju.
- ❖ Izaberemo Select gornje levo dugme
- ❖ I pod stavkom 2 nam piše IP adresa.

Za konfiguraciju telefona koristimo Web interface.

Web interface-u telefona pristupamo iz browser-a, unošenjem IP adrese telefona.

Ukoliko je definisan Web admin password, pojaviće se login prozor. Username je admin.

Nakon uspešnog logovanja dobijamo sledeću stranu:

LINKSYS[®]
A Division of Cisco Systems, Inc.

Linksys Telephone Configuration

Info | System | User

[Admin Login](#) | [basic](#) | [advanced](#)
[Personal Directory](#) | [Call History](#)

System Information

DHCP:	Enabled	Current IP:	192.168.52.190
Host Name:	SipuraSPA	Domain:	int.sezampro.rs
Current Netmask:	255.255.255.0	Current Gateway:	192.168.52.1
Primary DNS:	192.168.52.44		
Secondary DNS:	192.168.56.22		

Product Information

Product Name:	SPA-921	Serial Number:	4MJ00H508764
Software Version:	5.1.8	Hardware Version:	1.0.1(7583)
MAC Address:	000E08D3B7D4	Client Certificate:	Installed
Licenses:	None		

Phone Status

Current Time:	1/3/2003 12:41:31	Elapsed Time:	2 days and 00:41:31
Broadcast Pkts Sent:	2	Broadcast Bytes Sent:	684
Broadcast Pkts Recv:	381665	Broadcast Bytes Recv:	31433875
Broadcast Pkts Dropped:	0	Broadcast Bytes Dropped:	0
RTP Packets Sent:	0	RTP Bytes Sent:	0
RTP Packets Recv:	0	RTP Bytes Recv:	0
SIP Messages Sent:	0	SIP Bytes Sent:	0
SIP Messages Recv:	0	SIP Bytes Recv:	0
External IP:			

Ext 1 Status

Registration State:	Not Registered	Last Registration At:	
Next Registration In:		Message Waiting:	No
Mapped SIP Port:			

Predjite na polje **System** gde podešavate **DNS** servere:

Primary DNS: **77.105.0.18**

Secondary DNS: 77.105.0.19

LINKSYS[®]
A Division of Cisco Systems, Inc.

Linksys Telephone Configuration

Info **System** SIP Provisioning Regional Phone Ext 1 User [User Login](#) [basic](#) | [advanced](#)
[Personal Directory](#) [Call History](#)

System Configuration

Restricted Access Domains:

Enable Web Server: Web Server Port:

Enable Web Admin Access: Admin Passwd:

User Password:

Internet Connection Type

DHCP:

Static IP: NetMask:

Gateway:

Optional Network Configuration

HostName: Domain:

Primary DNS: Secondary DNS:

DNS Server Order: DNS Query Mode:

Syslog Server: Debug Server:

Debug Level: Primary NTP Server:

Secondary NTP Server:

VLAN Settings

Enable VLAN: VLAN ID:

Potom na polju **Phone** podešavamo **Station Name** i **Text logo**:

Station Name: Ime Korisnika

Text logo: [S]IT

LINKSYS[®]
A Division of Cisco Systems, Inc.

Linksys Telephone Configuration

Info System SIP Provisioning Regional **Phone** Ext 1 User [User Login](#) [basic](#) | [advanced](#)
[Personal Directory](#) [Call History](#)

General

Station Name: Ime Korisnika Voice Mail Number:

Text Logo: [S]IT

Line Key 1

Extension: 1 Short Name: \$USER

Share Call Appearance: private

Miscellaneous Line Key Settings

SCA Line ID Mapping: Vertical First SCA Barge-In Enable: no

Line Key LED Pattern

Supplementary Services

Conference Serv:	yes	Attn Transfer Serv:	yes
Blind Transfer Serv:	yes	DND Serv:	yes
Block ANC Serv:	yes	Call Back Serv:	yes
Block CID Serv:	yes	Secure Call Serv:	yes
Cfwd All Serv:	yes	Cfwd Busy Serv:	yes
Cfwd No Ans Serv:	yes	Paging Serv:	yes
Call Park Serv:	yes	Call Pick Up Serv:	yes
ACD Login Serv:	no	Group Call Pick Up Serv:	yes
ACD Ext:	1	Service Annc Serv:	no

Potom idite na polje **Ext 1** gde ćete podesiti **User Name, Password, Proxy** i **Preferred Codec**:

Proxy: **sip.sezampro.rs**

Preferred Codec: **G711a**

LINKSYS[®]
A Division of Cisco Systems, Inc.

Linksys Telephone Configuration

Info System SIP Regional Phone **Ext 1** User [User Login](#) [basic](#) | [advanced](#)
[Personal Directory](#) | [Call History](#)

General
Line Enable:

NAT Settings
NAT Mapping Enable: NAT Keep Alive Enable:

SIP Settings
SIP Port: SIP Debug Option:

Call Feature Settings
Message Waiting: Default Ring:
Mailbox ID:

Proxy and Registration
Proxy: Register:
Make Call Without Reg: Register Expires:
Ans Call Without Reg:

Subscriber Information
Display Name: User ID:
Password: Use Auth ID:
Auth ID:

Audio Configuration
Preferred Codec: Use Pref Codec Only:
Silence Supp Enable: DTMF Tx Method:

Nakon toga kliknite na **Submit All Changes**.